



# euro It | HYBRIDS



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

# euro lt | HYBRIDS

## Using Your Setup Instructions

The Euro LT Hybrids Setup Instructions are created specifically for your configuration. They are laid out sequentially in levels, including exploded views, and a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.


## Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts, countertops, or panels use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



## General Setup Instructions for Extrusion System




Most exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.




Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With extrusion components the labels contain Black numbers unless otherwise specified.



Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.




Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.




When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller section which then require assembly.


Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.




Each component has 2 clips, the lower clip is ALWAYS black. The top clip is color coded to distinguish which level. The color coded clip also contains the numbered label.



Components connect together by aligning them and sliding downward connecting clips together.



Configurations are assembled from left to right, usually starting with #1 and following the numbered sequence.



The first level of components contain panel locks that are located at the top of the panel for extra stability and seamless connection. When disassembling panels twist top connection slightly and lift right panel upward.

**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**

Modul Extrusion: Part List

Item	Qty.	Description
1	6	Base Plate
2	1	46.75"h Lowe Vertical Extrusion w/ Connector Attached
3	1	46.75"h Upper Vertical Extrusion w/ Connector Attached
6	1	46.75"h Lowe Vertical Extrusion w/ Connector Attached
7	1	46.75"h Upper Vertical Extrusion w/ Connector Attached
24	1	46.75"h Lowe Vertical Extrusion w/ Connector Attached
25	1	46.75"h Upper Vertical Extrusion w/ Connector Attached

EURO LT Panel System: Part List


Level 1

Item Number	Description
4	34"w x 47.5"h Flat Panel
8	34"w x 47.5"h Flat Panel

Level 2


Item Number	Description
5	34"w x 46"h Flat Panel w/ Wood Core
9	34"w x 46"h Flat Panel w/ Wood Core

866.652.2100



Steps:

- 1) Attach vertical extrusions [2, 6 and 24] to base plates [1]
- 2) Connect upper verticals to lower verticals as shown [3 to 2, 7 to 6 and 25 to 24].
- 3) Connect LT panels between vertical assemblies as indicated.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

## Steps:

- 1) Hook headers to top of assembled backwall.
- 2) Attach graphics to backwall upper panels as indicated.






WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL  
SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Item Number	Description
23	14.125" w x 30" h Flat Panel
24	30" h 90° Connector
25	23" w x 30" h Flat Panel w/ Door
26	30" h 90° Connector
27	14.125" w x 30" h Flat Panel
28	30" h 90° Connector
29	23" w x 30" h Flat Panel
30	30" h 90° Connector

- Steps:
- 1) Assemble by starting at panel #23\* and continue in numerical order.
  - 2) Velcro shelf supports to inside of assembled base.
  - 3) Set internal shelf atop supports.
  - 4) Place counter top on assembled base.
  - 5) Attach plex shelves to counter top using 8" stand-offs and caps.






WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Item Number	Description
31	28.5"w x 30"h Flat Panel
32	30"h 90° Connector
33	19"w x 30"h Flat Panel w/ Door
34	30"h 90° Connector
35	28.5"w x 30"h Flat Panel
36	30"h 90° Connector
37	19"w x 30"h Flat Panel
38	30"h 90° Connector

- Steps:
- 1) Assemble by starting at panel #31\* and continue in numerical order.
  - 2) Velcro shelf supports to inside of assembled base.
  - 3) Set internal shelf atop supports.
  - 4) Place counter top on assembled base.
  - 5) Attach plex shelf to counter top using (6) 8" stand-off, then secure with caps.



**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**