


Plan View



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

visionary™ IDESIGNS

Using Your Setup Instructions

The Visionary Designs Setup Instructions are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display, and then a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is **VERY IMPORTANT**.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or countertops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



The Tool

Most Visionary Designs exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Detail A

Typical Connection



Typical Connection (cont'd)

Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.



Detail B

Numbered Label


Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With Visionary Designs the labels contain Black numbers unless otherwise specified.



Detail C

Horizontal Inline Connection (remove only one setscrew)

Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.



Detail D

Base Plate Connection

Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.



Detail E

Vertical Connection (remove only two setscrews)

When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller sections which then require assembly.


Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Part Number	Qty for Step	Description
1	4	Base Plates
2	2	45.3750"h Lower Vertical extrusion
3	2	45.3750"h Upper Vertical extrusion
4	2	45.3750"h Lower Vertical extrusion
5	2	45.3750"h Upper Vertical extrusion
6	2	18" Lower Horizontal extrusion
7	2	18" Upper Horizontal extrusion
8a/8b	1/1	36.689" Lower Horizontal extrusion
9a/9b	1/1	36.689" Lower Horizontal extrusion
10	2	8" Header Support extrusion


Steps

- 1) Attach vertical extrusions [2 and 4] to the oval base plates [1], see detail D on general information page.
- 2) Place upper vertical extrusions [3 and 5] atop of lower vertical extrusions [2 and 4].
- 3) Assemble all horizontal extrusions together [8a to 8b and 9a to 9b].
- 4) Attach lower horizontals [6 and 8a/8b] between vertical assemblies [2/3 and 4/5] as shown.
NOTE: Velcro on Lower Horizontals must face DOWN.
- 5) Attach lower horizontals [7 and 9a/9b] between vertical assemblies [2/3 and 4/5] as shown.
NOTE: Velcro on Upper Horizontals must face UP.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100



Graphic Attachment


Attach round sign to assembled backwall using V20 connectors and caps.

Light Connection

Attach Lights to Backwall where desired and tighten in place.


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

6 - 45.375" Extrusions






Level 1

2 - 45.375" Extrusions



Level 2



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING