


Perfect 10 Hybrid Displays

Part Number	Description
1	Left Leg Assembly
1a	Back Leg
2	Right Leg Assembly
2a	Back Leg
3	Upper Curved Vertical
4	Upper Curved Vertical
5	23" w Horizontal w/ Knob Attachment
6	23" w Horizontal


NOTE: When assembling horizontals they should be placed approximately one inch from TOP and BOTTOM.





Steps:

- A) Attach back legs [1a and 2a] to leg assemblies [1 and 2] using splices [b].
- B) Connect vertical leg assemblies [1 and 2] together by connecting LOWER horizontal extrusion [5] between assemblies tightening BLACK knobs on backside to secure.
- C) Attach upper verticals [3 and 4] to top of leg assemblies [1 and 2] using vertical connection bars.
- D) Attach horizontals [6] with product rolls between leg assemblies, tightening setscrews to secure.
- E) Connect upper horizontal extrusion [5] between verticals [3 and 4].
- F) Attach literature racks into front groove of verticals where desired.

NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion back and forth while turning knob until lock fully opens.



Vertical Connection Bar
Slide Connection Bar into lower leg assembly. Slide upper vertical over bar and secure both.



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

visionary[™] DESIGNS

Using Your Setup Instructions

The Visionary Designs Setup Instructions are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display, and then a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.

Cleaning and Packing Your Display


- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or countertops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



Most Visionary Designs exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.




Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With Visionary Designs the labels contain Black numbers unless otherwise specified.



Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.



Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.



When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller sections which then require assembly.

Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.

WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING