



Item Qty. Description


- 1 1 38"h Vertical Extrusion w/ Door Stops
- 2 1 40"h Vertical Extrusion
- 3 1 40"h Vertical Extrusion
- 4 1 38"h Vertical Extrusion w/ Door Hinges
- 5 2 18.0868" Curved Horizontal Extrusion
- 6 4 13" Horizontal Extrusion
- 7 2 14" Horizontal Extrusion
- 8 2 35" Vertical Extrusion
- 9 1 14" Horizontal Extrusion


Steps:

- 1) Attach lower horizontal extrusions [5, 6 and 7] between vertical extrusions [1, 2, 3, and 4].
- 2) Place inserts and attach door where indicated.
- 3) Attach upper horizontal extrusions [5, 6 and 7] between vertical extrusions [1, 2, 3, and 4] and atop doors and inserts.
- 4) Velcro shelf supports to inside of assembled pedestal, then set internal shelf atop supprts.
- 5) Place counter top on assembled pedestal.
- 6) Attach vertical extrusions [8] atop lower verticals [2 and 3].
- 7) Connect horizontal extrusion [9] between vertical posts as shown.











Internal Shelf

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com





8

VISICERS

Using Your Setup Instructions DESIGNS The Visionary Designs Setup Instructions are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display, and then a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.

Cleaning and Packing Your Display 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only


- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or countertops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



Most Visionary Designs exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.



Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With Visionary Designs the labels contain Black numbers unless otherwise specified.



Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.



Base Plate Connection


Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

866.652.2100







Front View of Crate

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

866.652.2100