



euro It | HYBRIDS



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

euro lt | HYBRIDS

Using Your Setup Instructions

The Euro LT Hybrids Setup Instructions are created specifically for your configuration. They are laid out sequentially in levels, including exploded views, and a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.


Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts, countertops, or panels use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.


General Setup Instructions for Extrusion System




Most exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.




Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With extrusion components the labels contain Black numbers unless otherwise specified.



Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.




Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.




When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller section which then require assembly.


Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.




Each component has 2 clips, the lower clip is ALWAYS black. The top clip is color coded to distinguish which level. The color coded clip also contains the numbered label.



Components connect together by aligning them and sliding downward connecting clips together.



Configurations are assembled from left to right, usually starting with #1 and following the numbered sequence.



The first level of components contain panel locks that are located at the top of the panel for extra stability and seamless connection. When disassembling panels twist top connection slightly and lift right panel upward.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Item	Quantity	Description
1	2	96"h Square Vertical Extrusion
1A	2	96"h Square Vertical Extrusion w/ Base Plate Attachment
1B	1	96"h Square Vertical Extrusion w/ Permanently Attached S11 Connector
1C	1	96"h Square Vertical Extrusion w/ Permanently Attached S11 Connector
1D	2	Base Plate
2	8	37.189"w Curved Horizontal Extrusion w/ Shelf Attachment
2A	2	37.189"w Curved Horizontal Extrusion
2B	2	37.189"w Curved Horizontal Extrusion w/ Velcro Attached to Back Bottom Edge of Extrusion
2C	2	37.189"w Curved Horizontal Extrusion w/ Velcro Attached to Back Top Edge of Extrusion
3	2	37.189"w Curved Horizontal Extrusion w/ Velcro Attached to Back Bottom Edge of Extrusion
3A	2	37.189"w Curved Horizontal Extrusion w/ Velcro Attached to Back Top Edge of Extrusion
4	1	93.427"w Curved Horizontal Extrusion
4A	1	93.427"w Curved Horizontal Extrusion w/ Velcro Attached to Back Bottom Edge of Extrusion
4B	1	93.427"w Curved Horizontal Extrusion w/ Velcro Attached to Back Top Edge of Extrusion

Steps:

- 1) Attach vertical extrusions [1A] to base plates.
- 2) Connect horizontal extrusions [2, 2A and 2C] between vertical extrusions [1 and 1A] as shown, placing inserts as indicated.
- 3) Connect horizontal extrusions [3 and 3A] between vertical extrusions [1 and 1B] as shown.
- 4) Connect horizontal extrusions [4, 4A and 4B] between vertical extrusions [1B and 1C], placing inserts as indicated.
- 5) Apply graphics as indicated.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100




Item	Qty.	Description
5	2	93.427" w Horizontal Curved Extrusion
6	1	26.417" h Vertical Extrusion w/ Hinges for Door
7	1	26.417" h Vertical Extrusion w/ PR37 Door Stop
8		Small Internal Shelf Supports

- Steps:
- 1) Connect lower horizontal extrusion [5] between backwall extrusions [1B and 1C] from previous step.
 - 2) Attach vertical extrusions [6 and 7] and doors to horizontal extrusion [5].
 - 3) Connect upper horizontal extrusion [5] between backwall extrusions [1B and 1C] from previous step.
 - 4) Velcro shelf supports to inside of assembled alcove as shown. Then set internal shelf atop supports.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100








WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Item	Qty.	Description
1	2	96"h Square Vertical Extrusion
8	1	51.184" Horizontal Curved Extrusion
9	1	51.184" Horizontal Curved Extrusion
10a/10b	1/1	48.321" Horizontal Curved Extrusion
11a/11b	1/1	48.321" Horizontal Curved Extrusion
12	1	51.184" Horizontal Curved Extrusion
13	1	51.184" Horizontal Curved Extrusion

- Steps:
- 1) Connect horizontal curved extrusions together [10a to 10b and 11a to 11b].
 - 2) Attach horizontal extrusions [8 and 9] between vertical extrusions [1 and 1B].
 - 3) Attach assembled extrusion [10a/10b and 11a/11b] between vertical extrusions [1].
 - 4) Attach horizontal extrusions [12 and 13] between vertical extrusions [1 and 1C].
 - 5) Attach lights as indicated.
 - 6) attach literature racks to vertical extrusions [1] as shown.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Part Number	Qty for Step	Description
14	1	Base Plate
15	1	96" h Square Vertical Extrusion
16	1	103.4948" Vertical Curved Extrusion
17	1	15.182" w Horizontal Extrusion
18	1	17.663" w Horizontal Extrusion
19	1	15.182" w Horizontal Extrusion
22	1	Counter Support Leg

Steps


- 1) Attach vertical extrusion [15] to base plate [14].
- 2) Attach vertical curved extrusion [16] to Vertical extrusions [15].
- 3) Attach horizontal extrusions [17, 18 and 19] between vertical extrusions [15 and 16]
- 4) Connect horizontal extrusion [20] to vertical extrusion [21]. Then attach assembled extrusions to vertical extrusion [15] as shown.
- 5) Attach shelves to horizontal extrusions [17, 18 and 19] by using provided stand off caps.
- 6) Attach light and finial to vertical extrusions as shown.



Light Attachment

Slide light connector into groove of extrusion, tighten to secure connector.

Connect light to connector, then tighten to secure light.




QTY. 2

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Part Number	Qty for Step	Description
1	1	5.75"r X 38"h Quarter Curve Panel
2	1	23"w x 38"h Flat Panel
3	1	5.75"r X 38"h Quarter Curve Panel
4	1	5.75"r X 38"h Quarter Curve Panel
5	1	23"w x 38"h Flat Panel w/Door w/Lock
6	1	5.75"r X 38"h Quarter Curve Panel
23	1	Custom Base Plate
24	1	38"h Curved Round Vertical - Counter Support - Left side
25	1	38"h Curved Round Vertical - Counter Support - Right side
26	2	7" Lower Tapered Horizontal extrusion
27	1	8" Middle Tapered Horizontal extrusion
28	1	16.5" Upper Tapered Horizontal extrusion
	4	Large Internal Shelf Support



Steps for Back LT Portion of Pedestal:



Use Blue Labels for Step 1.

- 1) Assemble curve panel [1] to flat panel [2] and continue in numerical order.
- 2) Attach Internal Shelf with provided shelf supports.

Steps for Front - Aluminum Portion of Pedestal:

Use Black Labels for Steps 3 through 7.

- 3) Attach 38"h Curved Vertical Counter Supports [24 and 25] to Custom Base Plate [23].
note: Place Custom Base Plate Centered and Flushed with Back LT Portion of Pedestal.
- 4) Attach both 7" Lower Horizontal extrusion [26] between Curved Round Vertical Counter supports [24 and 25].
- 5) Attach 8" Middle Tapered Horizontal extrusion [27] between Curved Round Vertical Counter supports [24 and 25].
- 6) Attach 16.5" Upper Tapered Horizontal extrusion [28] between Curved Round Vertical Counter supports [24 and 25].
- 7) Attach Counter top with Thumbscrews.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING