



Perfect 10 Hybrid Displays




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Part Number	Description
1	Left Leg Assembly w/ A10 Clamps Attached
2	Middle Leg Assembly
3A	Upper Curved Vertical w/ A10 Clamps Attached
3	Upper Curved Vertical
4	23" w Horizontal
5	Right Leg Assembly
6	Upper Curved Vertical
7	69" w Horizontal w/ Hinge Facing UP
8	69" w Horizontal w/ Hinge Facing DOWN

NOTE: When assembling horizontals they should be placed approximately one inch from TOP and BOTTOM.





Steps:
NOTE: Assembly may be easiest if assembled face down on floor then lifted upright.




- 1) Connect vertical extrusions [3 and 3A] to leg assemblies [1 and 2] using vertical connection bar as shown.
- 2) Connect horizontal extrusions [4] between vertical assemblies by slightly tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.
- 3) Connect vertical extrusion [6] to leg assembly [5] using vertical connection bar as shown.
- 4) Connect horizontal extrusions [4] between vertical assemblies by slightly tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

NOTE: Make sure the lock is flush to groove in extrusion before tightening, to avoid the extrusion from popping out.




STAR indicates location of knobs on BACKSIDE of unit.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Header Attachment -
Attach Header support to Backwall
then attach header to velcro on support.




Decorative Blade Attachment

Slide A10 Clamp into groove of square extrusion.





When desired location is found, tighten set screw to secure.



Tighten black plastic set screw to secure Wing in place.



Attach extrusion [9] then attach decorative wing and blade by attaching A10's then wing.




Back Shelf Attachment



Shelf attaches to back of sections 1 and 2 by setting atop pins located on back left side.

Cubby Attachment



Shelf attaches to section 5 by setting atop pins located on right side and securing into place with thumbscrew on left.







When attaching counter you will need to first slide shelf onto back pin then set down on front pin.

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


866.652.2100

Part Number	Description
A	Left Leg Assembly
B	Right Leg Assembly
C	Horizontal Extrusion
D	Horizontal Extrusion w/ Door Stopper
E	Horizontal Extrusion
F	Horizontal Extrusion

- Steps:
- 1) Connect lower horizontal extrusion [C] between and FLUSH to bottom of leg assemblies [A and B] as shown.
 - 2) Insert laminated infill into middle grooves of leg extrusions and set atop lower horizontal extrusion [C].
 - 3) Attach extrusion door between leg assemblies [A and B] and atop laminated infill.
 - 4) Attach upper horizontal extrusion w/ door stopper [D] between leg assemblies [A and B], and set flush with top of legs [A and B].
 - 5) Attach lower horizontal extrusion [E] between leg assemblies [A and B] placing FLUSH to bottom of front curves.
 - 6) Insert laminated infill into front grooves of leg extrusions and set atop lower horizontal extrusion [E].
 - 7) Attach upper horizontal extrusion [F] between leg assemblies [A and B], atop laminated infill and FLUSH with top of legs [A and B] as shown.



Place internal shelf into workstation then place counter atop assembled workstation.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING