



euro It | HYBRIDS



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

euro lt | HYBRIDS

Using Your Setup Instructions

The Euro LT Hybrids Setup Instructions are created specifically for your configuration. They are laid out sequentially in levels, including exploded views, and a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.


Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts, countertops, or panels use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



General Setup Instructions for Extrusion System




Most exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.




Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With extrusion components the labels contain Black numbers unless otherwise specified.



Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.




Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.




When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller section which then require assembly.


Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.




Each component has 2 clips, the lower clip is ALWAYS black. The top clip is color coded to distinguish which level. The color coded clip also contains the numbered label.



Components connect together by aligning them and sliding downward connecting clips together.



Configurations are assembled from left to right, usually starting with #1 and following the numbered sequence.





The first level of components contain panel locks that are located at the top of the panel for extra stability and seamless connection. When disassembling panels twist top connection slightly and lift right panel upward.

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Item Number	Description
1	236.8"r x 90"h Curve Panel
2	236.8"r x 90"h Curve Panel w/ Hole for Stand-off Attachment
3	236.8"r x 90"h Curve Panel w/ Hole for Stand-off Attachment
4	236.8"r x 90"h Curve Panel
5	236.8"r x 90"h Curve Panel w/ Hole for Stand-off Attachment
6	236.8"r x 90"h Curve Panel w/ Hole for Stand-off Attachment
7	236.8"r x 90"h Curve Panel
8	90"h 90° Connector
9	11.5"w x 90"h Flat Panel
10	95"h 90° Connector
11	236.8"r x 95"h Curve Panel w/ Extrusion Track Attached for Graphic Attachment
12	236.8"r x 95"h Curve Panel w/ Extrusion Track Attached for Graphic Attachment
13	95"h 3-way Connector w/ Extrusion Track Attached for Graphic Attachment
14	11.5"w x 95"h Flat Panel
14A	95"h End Cap
15	236.8"r x 95"h Curve Panel w/ Extrusion Track Attached for Graphic Attachment
16	236.8"r x 95"h Curve Panel w/ Extrusion Track Attached for Graphic Attachment
17	95"h 3-way Connector w/ Extrusion Track Attached for Graphic Attachment
18	11.5"w x 95"h Flat Panel
18A	95"h End Cap
19	38"h Flex Connector

Steps:
 1) Assemble by starting at panel #1* and continue in numerical order.



* = Hole Location


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100



Item	Qty.	Description
1	4	Base Plate
2	2	89.75"h Vertical Extrusion
3	2	89.75"h Vertical Extrusion

Steps:

- 1) Attach vertical extrusions [2 and 3] to base plates [1], see detail D on general info page.
- 2) Attach 6" stand-off barrels to back of vertical extrusions, see stand-off attachment detail.
- 3) Attach vertical extrusions w/ stand-off attached to assembled backwall and secure with caps as shown.
- 4) Attach oval header graphic to vertical extrusions [3] using stand-off barrels and caps as shown.
- 5) Hook ceiling w/ puck lights to top of right section of backwall as shown.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING





WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100


Steps:

- 1) Attach conference table leg 5 to base plate 4, see detail D on General info page.
- 2) Attach counter to table leg with supplied hardware.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


866.652.2100




Plan View



Front View




Side View





WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


866.652.2100



Plan View







Front View






Side View

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


(1) Assembled Counter



Slide assembled bookshelf in crate as shown.

Crate 1

(1) Assembled Bookshelf




Slide assembled bookshelf in crate as shown.

Plex Shelves

Crate 2

(1) Assembled Small Bookshelf




Slide assembled bookshelf in crate as shown.

Crate 3

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


(1) Assembled Counter



Slide assembled bookshelf in crate as shown.

Crate 1

(1) Assembled Bookshelf




Slide assembled bookshelf in crate as shown.

Plex Shelves

Crate 2

(1) Assembled Small Bookshelf






Plex Shelves




Slide assembled bookshelf in crate as shown.

Crate 3

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING