


20'

10'



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



General Setup Instructions for Panel System


Using Your Setup Instructions

The Euro LT Hybrids Setup Instructions are created specifically for your configuration. They are laid out sequentially in levels, including exploded views, and a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.


Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.

Cleaning and Packing Your Display


- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts, countertops, or panels use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.




Each component has 2 clips, the lower clip is ALWAYS black. The top clip is color coded to distinguish the level. The color coded clip also contains the numbered label.



Components connect together by aligning them and sliding downward connecting clips together.



Configurations are assembled from left to right, usually starting with #1 and following the numbered sequence.



The first level of components contains panel locks that are located at the top of the panel for extra stability and a seamless connection. When disassembling panels, twist top connection slightly and lift right panel upward.


General Setup Instructions for Extrusion System



Most exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.




Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With extrusion components the labels contain Black numbers unless otherwise specified.



Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.



Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.



When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller sections which then require assembly.

Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.





WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

| Item | Qty. | Description |
|------|------|---|
| 1 | 1 | 84”h Lower Square Extrusion w/ Door Stopper |
| 2 | 1 | 84”h Lower Square Extrusion |
| 3 | 1 | 84”h Lower Square Extrusion |
| 4 | 1 | 84”h Lower Square Extrusion w/ Door Hinges |
| 4a | 1 | 38”h Connector Extrusion |
| 5 | 1 | 84”h Lower Square Extrusion w/ Door Stopper |
| 5a | 1 | 38”h Connector Extrusion |
| 6 | 1 | 84”h Lower Square Extrusion |
| 7 | 1 | 84”h Lower Square Extrusion |
| 8 | 1 | 84”h Lower Square Extrusion w/ Door Hinges |
| 9 | 1 | 84”h Lower Square Extrusion w/ Door Stopper |
| 10 | 1 | 84”h Lower Square Extrusion |
| 11 | 1 | 84”h Lower Square Extrusion |
| 12 | 1 | 84”h Lower Square Extrusion w/ Door Hinges |

| Item | Qty. | Description |
|--------|------|--|
| 13/13A | 12/6 | 12”w Horizontal Extrusion |
| 14 | 9 | 10”w Horizontal Extrusion |
| 15 | 1 | 60”w Horizontal Extrusion |
| 16 | 1 | 60”w Horizontal Extrusion w/ Velcro Attached |
| 17 | 1 | 60”w Horizontal Extrusion |
| 18 | 1 | 60”w Horizontal Extrusion w/ Velcro Attached |
| 19 | 1 | 40”w Horizontal Extrusion |
| 20 | 1 | 40”w Horizontal Extrusion |

- Steps:
- 1) Attach connectors to square verticals [4a to 4 and 5a to 5], see detail illustration.
 - 2) Attach horizontal extrusions [13, 13A and 14] between vertical extrusions, placing inserts where indicated.
 - 3) Attach horizontal extrusions [15, 16, 17 and 18] between vertical extrusions [4 and 5], placing insert where indicated.
 - 4) Attach horizontal extrusions [19 and 20] between vertical extrusions [8 and 9].
 - 5) Apply graphics to assembled backwall as indicated.
- Note:** See Plan View for extrusion orientation



* = Indicates Monitor Mount Location


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

| Item | Qty. | Description |
|------|------|--|
| 21 | 9 | 10"w Horizontal Extrusion |
| 22 | 4 | 34"w Curved Horizontal Extrusion |
| 23 | 1 | 38"h Vertical Extrusion w/ Door Stopper |
| 24 | 1 | 34.416"h Vertical Extrusion w/ Door Hinges |
| 25 | 1 | 34.416"h Vertical Extrusion w/ Door Hinges |
| 26 | 1 | 86.1238" Curved Round Extrusion |
| 27 | 1 | 10.552"w Horizontal Extrusion |
| 28 | 1 | 8.859"w Horizontal Extrusion |
| 29 | 1 | 86.1238" Curved Round Extrusion |
| 30 | 1 | 10.552"w Horizontal Extrusion |
| 31 | 1 | 8.859"w Horizontal Extrusion |

Steps:

- 1) Attach horizontal extrusions [21] between backwall vertical extrusions as shown.
- 2) Attach small doors as indicated.
- 3) Attach lower curved horizontal extrusions [22] between vertical extrusions [23] and backwall verticals as shown.
- 4) Attach vertical extrusions [24 and 25] to lower curved horizontal extrusions [22], leave loose.
- 5) Attach doors and place inserts as indicated.
- 6) Attach upper horizontal extrusions [22] between vertical extrusions [23] and backwall verticals as atop doors and inserts.
- 7) Attach curved extrusions [26 and 29] to backwall verticals [1 and 12] as indicated.
- 8) Assemble shelf supports [27, 28, 30 and 31] between curved extrusions and vertical extrusions as indicated.
- 9) Attach Acrylic shelves atop supports using screw caps.







WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

| Item | Qty. | Description |
|------|------|-----------------------------|
| 32 | 1 | Canopy Attachment Extrusion |
| 33 | 1 | Canopy Attachment Extrusion |
| 34 | 1 | Canopy Attachment Extrusion |

Steps:

- 1) Attach canopy attachment extrusions [32, 33 and 34] to top of assembled backwall where indicated.
 - 2) Place ceilings atop lip of horizontal extrusions, see details below.
 - 3) Set shelves atop pins.
- Note:* Pins should remain assembled with square vertical extrusions.
- 4) Velcro internal shelf supports to inside of counter, then set internal shelves atop supports.
 - 5) Set counters atop assembled backwall as shown.



Place counter atop back pins located on back verticals and set down on front horizontal.

Use door opening to install internal shelf. Velcro shelf supports to inside of counter, Place laminated shelf atop supports.

Place ceiling with puck light atop lip of extrusion.

Use door opening to install internal shelf. Velcro shelf supports to inside of counter, Place laminated shelf atop supports.

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



Using Your Setup Instructions

The Aero Overhead Sign Setup Instructions are created specifically for your configuration. They include an exploded view of the frame which is sequentially numbered. We encourage you to study the instructions before attempting to assemble your exhibit.



Connections are kept very simple: no tools. Everything assembles with push-button connectors and pre-connected horizontal sections.

Cleaning and Packing Your Display




- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.

Steps:

- 1) Connect canopy pieces together as shown.
- 2) Apply pillow case graphic to assembled canopy
- 3 Attach assembled to top of assembled backwall as indicated.



Connections are made by holding the button down and sliding the red tube into opposing tube until the connection is made. To disassemble push button and pull or twist extrusions apart.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Euro LT Panels





| Item Number | Description |
|-------------|--------------------------------------|
| 1 | 14.125" w x 38" h Flat Panel w/ Door |
| 2 | 5.75" r x 38" h Half Curve Panel |
| 3 | 14.125" w x 38" h Flat Panel |
| 4 | 5.75" r x 38" h Half Curve Panel |

Modul Extrusions

| Item | Qty. | Description |
|------|------|-----------------------------|
| 35 | 2 | Base Plate |
| 36 | 2 | 37.75" h Vertical Extrusion |
| 37 | 2 | Horizontal Extrusion |
| 38 | 2 | Counter Support Extrusion |

Steps:

- 1) Connect panels #1 thru 4 together to create counter base.
- 2) Attach vertical extrusions [36] to base plates [35], see detail D on general information page.
- 3) Attach horizontal extrusions [37] between square vertical extrusions [36]
- 4) Attach extrusions [38] to vertical extrusions
Note: Extrusions [38] must be flush with top of square verticals.
- 5) Attach acrylic shelf atop counter using 4" stand-off and caps.
- 6) Set counter with shelf atop assembled bases.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING