



Perfect 10 Hybrid Displays



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Part Number	Description
5	Leg Assembly
6	Curved Vertical
9	Leg Assembly
10	Curved Vertical w/ A10 Clamps Attached
11	69" w Horizontal w/ Hinge Facing UP
12	69" w Horizontal w/ Hinge Facing DOWN
18	Upper Curved Vertical
19	Upper Curved Vertical

NOTE: Brown Section indicates extra components for creating 10' high configuration.



Step 3:

NOTE: Can be assembled either face down on floor then lifted upright or upright as shown in drawings.

A) Connect vertical extrusions to leg assemblies [6 to 5 and 12 to 11] using vertical connection bar as shown.

For 8' high Configuration


B) Connect horizontal extrusions [9 and 10] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

For 10' high Configuration



B) Connect upper curve extrusions [19] to curved verticals [12] using vertical connection bar as shown.

C) Connect horizontal extrusions [9 and 10] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.



STAR indicates location of knobs on BACKSIDE of unit.



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Part Number	Description
13	Leg Assembly w/ A10 Clamps Attached
14	Curved Vertical w/ A10 Clamps Attached
15	23" w Horizontal
20	Upper Curved Vertical w/ A10 Clamps Attached

NOTE: Brown Section indicates extra components for creating 10' high configuration.



Step 4:

NOTE: Can be assembled either face down on floor then lifted upright or upright as shown in drawings.

A) Connect vertical extrusion [14] to leg assembly [13] using vertical connection bar as shown.

For 8' high Configuration


B) Connect horizontal extrusions [15] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

For 10' high Configuration


B) Connect upper curve extrusions [20] to curved verticals [14] using vertical connection bar as shown.

C) Connect horizontal extrusions [15] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.


NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.



STAR indicates location of knobs on BACKSIDE of unit.




Turn Knob Clockwise to Tighten Lock




Slide Connection Bar into lower leg assembly. Slide upper vertical over bar and secure both.




WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING




**Decorative Blade Attachment
(if accidentally removed)**
Slide A10 Clamp into groove of square extrusion.




When desired location is found, tighten set screw to secure.





Attach decorative wing and blades to A10's attached to Backwall as shown.




Tighten black plastic set screw to secure Wing in place.



Hex Key Tool

(if necessary)

Flathead Screwdriver




WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING


Accessory Attachment
 Attach Header support to backwall, then Velcro header to horizontal bar as shown

Header

Velcro Applied to Front of horizontal bar.

Light Connection
 Attach Lights to Backwall where desired and tighten in place.

Shelf attaches to back of sections 1 and 2 by setting atop pins located on back left side.



Cubby Attachment

Shelf attaches to section 5 by setting atop pins located on right side and securing into place with thumbscrew on left.

Slide onto back pin first.

When attaching counter you will need to first slide shelf onto back pin then set down on front pin.

WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING