





# Perfect 10 Hybrid Displays



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING


# Perfect 10 Hybrid Displays



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Case #1 - Backwall Components

Top View of each Level



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Part Number	Description
5	Leg Assembly
6	Curved Vertical
7	69" w Horizontal w/ Hinge Facing UP
8	69" w Horizontal w/ Hinge Facing DOWN
18	Upper Curved Vertical

**NOTE:** Brown Section indicates extra components for creating 10' high configuration.



**Step 2:**

NOTE: Can be assembled either face down on floor then lifted upright or upright as shown in drawings.

A) Connect vertical extrusion [6] to leg assembly [5] using vertical connection bar as shown.

**For 8' high Configuration**



B) Connect horizontal extrusions [7 and 8] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

**For 10' high Configuration**


B) Connect upper curve extrusions [18] to curved verticals [6] using vertical connection bar as shown.

C) Connect horizontal extrusions [7 and 8] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

**NOTE:** Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.



**STAR** indicates location of knobs on BACKSIDE of unit.




**WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING**

866.652.2100

Part Number	Description
9	Leg Assembly
10	Curved Vertical w/ A10 Clamps Attached
11	69" w Horizontal w/ Hinge Facing UP
12	69" w Horizontal w/ Hinge Facing DOWN
19	Upper Curved Vertical

**NOTE:** Brown Section indicates extra components for creating 10' high configuration.



**Step 3:**

NOTE: Can be assembled either face down on floor then lifted upright or upright as shown in drawings.

A) Connect vertical extrusion [12] to leg assembly [11] using vertical connection bar as shown.

**For 8' high Configuration**


B) Connect horizontal extrusions [9 and 10] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

**For 10' high Configuration**




B) Connect upper curve extrusions [19] to curved verticals [12] using vertical connection bar as shown.

C) Connect horizontal extrusions [9 and 10] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

**NOTE:** Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.



**STAR** indicates location of knobs on BACKSIDE of unit.



Slide Connection Bar into lower leg assembly. Slide upper vertical over bar and secure both.

Vertical Connection Bar



Top Horizontal Hinge faces down.  
Bottom Horizontal Hinge faces up.

**WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING**

866.652.2100

Part Number	Description
13	Leg Assembly w/ A10 Clamps Attached
14	Curved Vertical w/ A10 Clamps Attached
15	23" w Horizontal
20	Upper Curved Vertical w/ A10 Clamps Attached

**NOTE:** Brown Section indicates extra components for creating 10' high configuration.



**Step 4:**

NOTE: Can be assembled either face down on floor then lifted upright or upright as shown in drawings.

A) Connect vertical extrusion [14] to leg assembly [13] using vertical connection bar as shown.

**For 8' high Configuration**



B) Connect horizontal extrusions [15] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

**For 10' high Configuration**


B) Connect upper curve extrusions [20] to curved verticals [14] using vertical connection bar as shown.

C) Connect horizontal extrusions [15] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

**NOTE:** Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.




**STAR** indicates location of knobs on BACKSIDE of unit.




**WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING**



**Decorative Blade Attachment**  
*(if accidentally removed)*  
Slide A10 Clamp into groove of square extrusion.




When desired location is found, tighten set screw to secure.



Attach decorative wing and blades to A10's attached to Backwall as shown.





Tighten black plastic set screw to secure Wing in place.




Set-Screw


Black Plastic Set-screw



**Hex Key Tool**  
*(if necessary)*



**Flathead Screwdriver**



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

866.652.2100

**Accessory Attachment**  
Attach Header support to backwall, then Velcro header to horizontal bar as shown

Header

Velcro Applied to Front of horizontal bar.

**Light Connection**  
Attach Lights to Backwall where desired and tighten in place.

Shelf attaches to back of sections 1 and 2 by setting atop pins located on back left side.

Thumbscrew

Pins

**Cubby Attachment**

Shelf attaches to section 5 by setting atop pins located on right side and securing into place with thumbscrew on left.

Slide onto back pin first.

When attaching counter you will need to first slide shelf onto back pin then set down on front pin.



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Part Number	Description
A	Left Leg Assembly
B	Right Leg Assembly
C	Horizontal Extrusion
D	Horizontal Extrusion w/ Door Stopper

Step 1:

- A) Connect lower horizontal extrusion [C] between bottom of leg assemblies [A and B] as shown.
- B) Insert Laminated infill into grooves of leg assemblies [A and B].
- C) Attach extrusion door between leg assemblies [A and B] and atop laminated infill.
- D) Attach upper horizontal extrusion w/ door stopper [D] between leg assemblies [A and B], and set flush with top of legs [A and B].

**NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion back and forth while turning knob until lock fully opens.**




**WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING**


Part Number	Description
E	Horizontal Extrusion
F	Horizontal Extrusion

Step 2:

- A) Attach horizontal extrusion [E] between vertical leg assemblies [A and B] as shown below.
- B) Insert Laminated infill into grooves of vertical leg assemblies [A and B].
- C) Attach upper horizontal extrusion [F] between vertical leg assemblies [A and B] atop infill.
- D) Place internal shelf into assembled pedestal atop pins..
- E) Set Counter atop assembled pedestal and secure with Velcro straps attached to underside of top.




Place internal shelf into workstation then place counter atop assembled workstation.



**WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING**

Case #1 - 10'x10' Backwall Components


Top View of each Level



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING


Case #2 - 10'x10' Backwall Components

Top View of each Level




WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Case #3 - 10'x10' Backwall Components




WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Case #4 - 10'x10' Backwall Components



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Case #5 - Workstation Components



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING