



euro It | HYBRIDS



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

euro lt | HYBRIDS

Using Your Setup Instructions

The Euro LT Hybrids Setup Instructions are created specifically for your configuration. They are laid out sequentially in levels, including exploded views, and a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts, countertops, or panels use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.

General Setup Instructions for Extrusion System



The Tool

Most exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Typical Connection

Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.



Typical Connection (cont'd)




Numbered Label

Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With extrusion components the labels contain Black numbers unless otherwise specified.




Horizontal Inline Connection (remove only one setscrew)

Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.



Base Plate Connection


Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.



Vertical Connection (remove only two setscrews)


When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller section which then require assembly.

Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.




Connector

Each component has 2 clips, the lower clip is ALWAYS black. The top clip is color coded to distinguish which level. The color coded clip also contains the numbered label.




Cut Away View Of Slide Clips

Components connect together by aligning them and sliding downward connecting clips together.



Example of Connection

Configurations are assembled from left to right, usually starting with #1 and following the numbered sequence.



Top View of Panels with Locks

The first level of components contain panel locks that are located at the top of the panel for extra stability and seamless connection. When disassembling panels twist top connection slightly and lift right panel upward.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Part Number	Qty for Step	Description
1	1	42" h Lower Vertical Extrusion
2	1	53" h Upper Vertical Extrusion
3	1	42" h Lower Vertical Extrusion
4	1	53" h Upper Vertical Extrusion
5	6	12" Horizontal Extrusion
6	1	47.2" Miter Cut Horizontal Extrusion
7	1	47.2" Miter Cut Horizontal Extrusion
8	1	47.2" Miter Cut Horizontal Extrusion
9	1	47.2" Miter Cut Horizontal Extrusion
10	1	47.2" Miter Cut Vertical Extrusion
11	1	47.2" Miter Cut Vertical Extrusion
12	1	47.2" Miter Cut Vertical Extrusion
13	1	47.2" Miter Cut Vertical Extrusion

Steps

- 1) Attach lower vertical extrusion [1] to upper vertical extrusion [2].
- 2) Attach lower vertical extrusion [3] to upper vertical extrusion [4].
- 3) Connect horizontal extrusions [5] to assembled verticals [1/2 and 3/4] placing inserts as shown.
- 4) Assemble Graphic frame by connecting extrusions [6 to 7, 8 to 9, 10 to 11 and 12 to 13] then connect assembled portions as shown in illustration.

NOTE 10 x 10 Frame uses verticals 10/11 and 12/13.
 Horizontals are numbered 6A and 8A.



Note: Attaching Graphics

****** Attach Backwall Graphics to Frame by inserting rubber gasket into groove on Front of frame.


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Item Number	Description
1	38" w x 42" h Flat Panel
2	42" h 90° Connector
3	38" w x 42" h Flat Panel
4	38" w x 42" h Flat Panel
5	38" w x 42" h Flat Panel
6	42" h 90° Connector
7	46" w x 42" h Flat Panel
8	57.5" r x 42" h Curve Panel
9	57.5" r x 42" h Curve Panel
10	11.5" w x 47.5" h Flat Panel
11	46" w x 47.5" h Flat Panel
12	19" w x 42" h Flat Panel
13	42" h 90° Connector
14	23" w x 42" h Flat Door Panel
15	42" h 90° Connector
16	19" w x 42" h Flat Panel
17	42" h 90° Connector
18	23" w x 42" h Flat Panel
19	42" h 90° Connector
20	14.125" w x 42" h Flat Panel
21	42" h 90° Connector
22	28.5" w x 42" h Flat Door Panel
23	42" h 90° Connector
24	14.125" w x 42" h Flat Panel
25	42" h 90° Connector
26	28.5" w x 42" h Flat Panel
27	42" h 90° Connector
28	38" w x 42" h Flat Door Panel
29	42" h 90° Connector
30	30" w x 42" h Flat Panel
31	42" h 90° Connector
32	38" w x 42" h Flat Panel
33	42" h 90° Connector
34	30" w x 42" h Flat Panel
35	42" h 90° Connector

Steps:
Connect panels together in numerical order as shown in illustrations.

Place internal shelves as shown.



Modul Extrusions

Item Number	Description
14	42" h Vertical Square Extrusion
27	37.961" Horizontal Extrusion
28	37.961" Horizontal Extrusion


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Level 2

Item Number	Description
1	38" w x 38" h Flat Panel
2	38" h 90° Connector
3	38" w x 38" h Flat Panel
10	11.5" w x 47.5" h Flat Panel
11	46" w x 47.5" h Flat Panel

Steps:
Connect panels together in numerical order as shown in illustrations.



Level 3


Item Number	Description
1	38" w x 15" h Flat Panel
2	15" h 90° Connector
3	38" w x 15" h Flat Panel

Steps:
Connect panels together in numerical order as shown in illustrations.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100



Place Counter atop assembled Pedestal.

Laminated White Cap

Place Counter atop assembled Pedestal.

Shelf

Insert

Post

Counter

Bolt

Attach Both Posts to shelf by screwing them in placing to the threaded stud attached to shelf.
Place Insert between posts as shown.
Place shelf assembly atop Counter and screw using bolts provided into place as shown.



Attach Sintra Caps atop Panels as shown via Velcro.

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Part Number	Qty for Step	Description
15	1	47.5" h Lower Vertical extrusion
16	1	47.5" h Upper Vertical extrusion
17	1	47.5" h Lower Vertical extrusion
18	1	47.5" h Upper Vertical extrusion
19	1	47.5" h Lower Vertical extrusion
20	1	47.5" h Upper Vertical extrusion
21	1	47.5" h Lower Vertical extrusion
22	1	47.5" h Upper Vertical extrusion
23/23A	3/1	21" w Horizontal extrusion
24/24A	3/1	32.5" w Horizontal extrusion
25/25A	3/1	21" w Horizontal extrusion
26/26A	3/1	32.5" w Horizontal extrusion

Steps

- 1) Connect vertical extrusions together as shown in illustration, [15 to 16, 17 to 18, 19 to 20, and 21 to 22].
- 2) Connect vertical assembly [17/18] to Panels [11/11] from previous steps.
- 3) Connect horizontal extrusions [23] between vertical assemblies [15/16 and 17/18] placing inserts as shown.
- 4) Connect horizontal extrusions [24] between vertical assemblies [17/18 and 19/20] placing inserts as shown.
- 5) Connect horizontal extrusions [25] between vertical assemblies [15/16 and 21/22] placing door and insert as shown.
- 6) Connect horizontal extrusions [26] between vertical assemblies [19/20 and 21/22] placing inserts as shown.





WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100




Qty for Step	Description
4	Internal Shelf Support

- Steps
- 1) Place internal shelf supports to velcro inside assembled showcase as shown.
 - 2) Place internal shelf atop supports.
 - 3) Place counter atop horizontal extrusions as shown.
 - 4) Place ceiling into upper portion of ceiling atop lip on extrusions.
 - 5) Attach slanted shelving to showcase as shown.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


866.652.2100



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



Front View of Crate




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



Full Front View

Level 1



Level 2



Level 3



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING