



euro It | *HYBRIDS*



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

euro lt | HYBRIDS

Using Your Setup Instructions

The Euro LT Hybrids Setup Instructions are created specifically for your configuration. They are laid out sequentially in levels, including exploded views, and a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts, countertops, or panels use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.


General Setup Instructions for Extrusion System



Most exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.




Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With extrusion components the labels contain Black numbers unless otherwise specified.



Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.




Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.




When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller section which then require assembly.


Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.




Each component has 2 clips, the lower clip is ALWAYS black. The top clip is color coded to distinguish which level. The color coded clip also contains the numbered label.



Components connect together by aligning them and sliding downward connecting clips together.



Configurations are assembled from left to right, usually starting with #1 and following the numbered sequence.



The first level of components contain panel locks that are located at the top of the panel for extra stability and seamless connection. When disassembling panels twist top connection slightly and lift right panel upward.


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Part Number	QTY.	Description
1	3	Base Plate
2	1	80"h Vertical Extrusion
3	1	80"h Vertical Extrusion
4	1	80"h Vertical Extrusion
5/5a	2/1	40"w Horizontal Extrusion
6	1	42.5"w Horizontal Extrusion
7	1	42.5"w Horizontal Extrusion
8	1	42.5"w Horizontal Extrusion

Steps

- 1) Attach vertical extrusions [2, 3 and 4] to base plates [1].
- 2) Connect horizontal extrusions [5 and 5a] between vertical extrusions [2 and 3], placing inserts where indicated.
- 3) Connect horizontal extrusions [6, 7 and 8] between vertical extrusions [3 and 4].





WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

© 2009

Part Number	QTY.	Description
9	1	Shelf Support
9a	1	Shelf Support

Steps

- 1) Attach shelf supports [9 and 9a] to backwall horizontal [5a].
- 2) Set shelf atop counter supports.
- 3) Attach wing panel to A10 clamps, see A10 attachment details.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100


Part Number	Description
A	8.738" Mitered Extrusion
B	14" Extrusion
C	92.9" Curved Extrusion
D	89.965" Extrusion

Steps



- 1) Connect horizontal extrusion [D] between vertical extrusions [A and B] as shown.
- 2) Attach curved horizontal extrusion [C] atop vertical extrusions [A and B] as shown.
- 3) Attach ceiling pieces together, see ceiling attachment details.
- 4) Attach assembled header frame to assembled ceiling using bolts.
- 5) Apply rollable graphic on assembled header frame.
- 6) Velcro graphic header onto rollable graphic.



Velcro attached to FRONT of header frame.



Connect counter pieces together using bolts washer and wing nuts



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Lower Level

Item Number	Description
1	23" w x 38" h Flat Panel w/ Door
2	23" w x 38" h Flat Panel w/ Door
3	38" h 90° Connector
4	19" w x 38" h Flat Panel
5	38" h 90° Connector
6	23" w x 38" h Flat Panel
7	23" w x 38" h Flat Panel
8	38" h 90° Connector
9	19" w x 38" h Flat Panel
10	38" h 90° Connector

Upper Level



Item Number	Description
1	23" w x 38" h Flat Panel
2	23" w x 38" h Flat Panel
3	38" h 90° Connector
4	19" w x 38" h Flat Panel
5	38" h 90° Connector
6	23" w x 38" h Flat Panel
7	23" w x 38" h Flat Panel
8	38" h 90° Connector
9	19" w x 38" h Flat Panel w/ Door
10	38" h 90° Connector

Steps:

- 1) Assemble by starting at panel #1* and continue in numerical order.
- DO NOT ASSEMBLE** panels #9 and 10 until shelves are in place.

Steps:

- 1) Assemble by starting at panel #1* and continue in numerical order.
- DO NOT ASSEMBLE** panels #9 and 10 until shelves are in place.





WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Steps:


- 1) Attach adjustable pins where indated.
- 2) Place shelves atop pins.

Steps (Cont'd):

- 3) Attach lower level panel #9 and connector #10 to tower.
- 4) Attach upper level panel #9 and connector #10 to tower atop lower level.



☆ = Indicates Pin for Shelf Placement






WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Part Number	QTY.	Description
10	4	36" h Vertical Extrusion
11	1	36" h Vertical Extrusion w/ Door Hinges
12	1	36" h Vertical Extrusion w/ Door Stop
13	4	22.625" w Horizontal Extrusion
14	8	6.75" w Horizontal Extrusion

Steps

- 1) Attach horizontal extrusions [13 and 14] between vertical extrusions as shown.
- 2) Assemble shelf support pieces together.
- 3) Attach assembled shelf supports to vertical extrusions [10] where indicated.
- 4) Place inserts and attach door.
- 5) Attach upper horizontal extrusions [13 and 14] between vertical extrusions and atop atop door and inserts.






WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


866.652.2100

Part Number	QTY.	Description
15	4	Horizontal Extrusion
16	2	70.25"h Vertical Extrusion


- Steps
- 1) Connect vertical extrusions [16] to assembled base using horizontal extrusions [15].
 - 2) Attach graphic between vertical extrusions [16] using Gyford Grippers, see detail attachment below.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



Level 3




Level 2



Level 1

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING