



euro It | *HYBRIDS*



Plan View

10'

10'



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

euro lt | HYBRIDS

Using Your Setup Instructions

The Euro LT Hybrids Setup Instructions are created specifically for your configuration. They are laid out sequentially in levels, including exploded views, and a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts, countertops, or panels use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.


General Setup Instructions for Extrusion System




Most exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.




Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With extrusion components the labels contain Black numbers unless otherwise specified.



Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.




Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.




When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller section which then require assembly.


Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.




Each component has 2 clips, the lower clip is ALWAYS black. The top clip is color coded to distinguish which level. The color coded clip also contains the numbered label.



Components connect together by aligning them and sliding downward connecting clips together.



Configurations are assembled from left to right, usually starting with #1 and following the numbered sequence.



The first level of components contain panel locks that are located at the top of the panel for extra stability and seamless connection. When disassembling panels twist top connection slightly and lift right panel upward.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Part Number	Description
1	5.75"r x 47.5"h Half Curve
2	5.75"r x 47.5"h Half Curve
3	5.75"r x 47.5"h Half Curve
4	5.75"r x 47.5"h Half Curve
5	23"w x 42"h Flat Panel
6	11.5"r x 42"h Curved Panel
7	11.5"r x 42"h Curved Panel
8	23"w x 42"h Flat Panel w/ Door
9	23"w x 42"h Flat Panel w/ Door
10	11.5"r x 42"h Curved Panel
11	11.5"r x 42"h Curved Panel
12	23"w x 42"h Flat Panel
13	23"w x 42"h Flat Panel w/ Door
14	42"h 90° Corner Connector
15	11.5"r x 42"h Curved Panel
16	11.5"r x 42"h Curved Panel
17	42"h 90° Corner Connector

Steps

- 1) Assemble panels [1 to 2 and 3 to 4] then place into columns supports as shown in detail below.
- 2) Continue assembling panels in numerical order as shown.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



866.652.2100

Part Number	Description
1	5.75"r x 47.5"h Half Curve
2	5.75"r x 47.5"h Half Curve
3	5.75"r x 47.5"h Half Curve
4	5.75"r x 47.5"h Half Curve

Steps

1) Assemble panels [1 to 2 and 3 to 4] atop assembled lower panels.

NOTE: Before attaching the second upper panel use the Velcro Panel Tie to secure Upper and Lower Panels together.






WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Part Number	Qty	Description
2	1	82.6" Curved Extrusion
3	1	82.6" Curved Extrusion
4	2	78.965"h Vertical Extrusion

Steps

- 1) Attach curved horizontal extrusions [2 and 3] between columns by attaching to S10 extrusion, refer to detail below.
- 2) Connect vertical extrusions [4] between curved horizontal extrusions as shown.
- 3) Attach graphic to curved extrusions by wrapping around Top and Bottom.




Note: Attaching Graphics
 Attach Backwall Graphics to Velcro by wrapping the Graphic over the Top of the Upper Horizontals and under the Bottom of the Lower Horizontals

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Part Number	Description
1	Curved Counter Support


Steps
1) Refer to Details below.



Curved Round Vertical Counter Support - -
1. Attach both 3"d Base & Top Plates to the 38"h Curved Round Vertical #1.
2. Attach Counter Top to Vertical support.
3. Connect to Panels using thumbscrews and rest atop bolts.




Attach Front Counter Top using Thumbscrews.



Insert Bolt for Counter to rest on

Insert Bolt for Counter to rest on



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



866.652.2100


Using Your Setup Instructions

The Aero Overhead Sign Setup Instructions are created specifically for your configuration. They include an exploded view of the frame which is sequentially numbered. We encourage you to study the instructions before attempting to assemble your exhibit.






Connections are kept very simple: no tools. Everything assembles with push-button connectors and pre-connected horizontal sections.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.




Connections are made by holding the button down and sliding the red tube into opposing tube until the connection is made. To disassemble push button and pull or twist extrusions apart.



Assemble Frame in alphabetical order as shown. Then using hools on frame attach to top of Curved panels as shown.

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



Top Shelf



Front View

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING