

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

visionary™ IDESIGNS

Using Your Setup Instructions

The Visionary Designs Setup Instructions are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display, and then a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is **VERY IMPORTANT**.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or countertops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



The Tool

Most Visionary Designs exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.



Typical Connection

Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.



Typical Connection (cont'd)



Detail B

Numbered Label


Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With Visionary Designs the labels contain Black numbers unless otherwise specified.



Detail C

Horizontal Inline Connection (remove only one setscrew)


Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.



Detail D

Base Plate Connection

Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.



Detail E

Vertical Connection
(remove only two setscrews)


When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller sections which then require assembly.

Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

SEG Graphic Installation

Graphic: To Ensure Proper Fit




It is important to first insert graphic into each alternater corner then to the sides of the frame.
If this is not done, graphic will not fit into the frame correctly.



Step 1
Insert corner A.
Turn edge of graphic so silicon welt is perpendicular to face of graphic. Insert narrow side of welt with fabric to outside into the channel. Repeat for other side of this corner.




Step 2
Repeat Step 1 for opposite corner C, then insert corner B, followed by corner corner D, to complete the installation of the corners.



Step 3
Once all corners are inserted, press one silicon edge into channel from corners and work toward the center. Make sure welt is fully inserted into channel. Continue until all sides are done. Smooth out edges of graphic.

Graphic Removal



To remove the graphic from the frame, locate the fabric pull tab. Gently pull up on the tab to remove the fabric.



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Part Number	Qty	Description
1	12	55"h SEG Extrusion


Steps

- 1) Place upper towers atop lower towers and secure with bolts.
- 2) Attach tower assemblies to base and secure with wing nuts underneath base.
SEG extrusions or holes for extrusion attachment must face inside of structure
- 3) Lift assembled tower with base upright.
- 4) Attach SEG extrusions [1] to towers where indicated.
***** See next page diagram for tower locations *****



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Part Number	Qty	Description
1	12	55"h SEG Extrusion
2	6	74"h SEG Extrusion
3	6	74"h SEG Extrusion


Steps

- 1) Attach SEG horizontal extrusions between SEG vertical extrusions from previous steps.
- 2) Apply SEG graphics to assembled frame, refer to graphic attachment detail page.
- 3) Lock 4 light attachment pieces [4] into top groove of extrusion [3] where desired.
- 4) Repeat steps for all towers.

S10 track permanently attached to SEG extrusion #3
GROOVE MUST FACE UP



*** Use PR63 plastic wire cover for wire management ***
3 pieces on each frame



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100


Part Number	Qty	Description
5	2	88.855" Curved Horizontal Extrusion
6	2	88.855" Curved Horizontal Extrusion
7	2	88.855" Curved Horizontal Extrusion
8	2	88.855" Curved Horizontal Extrusion
9A-E	9	108"w Extrusion
10	4	34.629"w Curved Extrusion

Steps

- 1) Connect curved horizontals together [5 to 6 to 7 to 8].
- 2) Connect horizontals [9] between curved assemblies from previous step.

*** See below illustration for cross bar locations and stoppers ***


Arrow indicates small stopper inside groove



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

*** NOTE - 4-6 People Assembly ***





Must have at least 2 people on each side of canopy for setup


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Part Number	Qty	Description
11	1	96" h Vertical Extrusion w/ Door Hinges
11a	1	96" h SEG Extrusion
12	1	96" h Vertical Extrusion w/ Door Stop
13	1	96" h Vertical Extrusion
14	1	96" h Vertical Extrusion
15	1	96" h Vertical Extrusion
16	2	88.835" w SEG Extrusion
17	3	28.835" w Horizontal Extrusion
18	4	42.626" w Horizontal Extrusion

- Steps
- 1) Attach door threshold to verticals [11 and 12].
 - 2) Connect horizontal extrusions between verticals, placing inserts where indicated.





This SEG extrusion must remain attached to #15




*** Attach Door Threshold First


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



Crate 2



Crate 3

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING