



# Perfect 10 Hybrid Displays




WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Part Number	Description
1	Left Leg Assembly
2	Right Leg Assembly
4	Upper Curved Vertical
5	Upper Curved Vertical
9	23" w Horizontal

Step 1:

NOTE: Can be assembled either face down on floor then lifted upright or upright as shown in drawings.




- A) Connect vertical leg assemblies [1 and 2] together by connecting horizontal extrusion [9] between assemblies tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK and placing it about one inch up from bottom and tightening.
- B) Connect vertical extrusions [4 and 5] to leg assemblies [1 and 2] using vertical connection bars as shown.
- C) Connect upper horizontal extrusion [9] between verticals [4 and 5] placing it about one inch down from top.

NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.

Rear View of Display




STAR indicates location of knobs on BACKSIDE of unit.



Turn Knob Clockwise to Tighten Lock

Step 1



NOTE: When assembling horizontals they should be placed approximately one inch from TOP and BOTTOM.



Slide horizontal into groove

Assure that a good connection is made and tighten to secure.

Slide Connection Bar into lower leg assembly. Slide upper vertical over bar and secure both.

Step stool may be required for assembly.



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Part Number	Description
3	Right Leg Assembly
5	Upper Curved Vertical
7	69" w Horizontal w/ Hinge Facing UP
8	69" w Horizontal w/ Hinge Facing DOWN

Step 2

Step 2:


NOTE: Can be assembled either face down on floor then lifted upright or upright as shown in drawings.

- A) Connect vertical extrusion [5] to leg assembly [3] using vertical connection bar as shown.
- B) Connect horizontal extrusions [7 and 8] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.


**NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.**





NOTE: When assembling horizontals they should be placed approximately one inch from TOP and BOTTOM.




Rear View of Display



STAR indicates location of knobs on BACKSIDE of unit.



Slide Connection Bar into lower leg assembly. Slide upper vertical over bar and secure both.



Part Number	Description
3	Right Leg Assembly
5	Upper Curved Vertical
9	23" w Horizontal

Step 3:  
 NOTE: Can be assembled either face down on floor then lifted upright or upright as shown in drawings.


- A) Connect vertical extrusion [5] to leg assembly [3] using vertical connection bar as shown.
- B) Connect horizontal extrusion [9] between vertical assemblies by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

**NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.**



Step 3

NOTE: When assembling horizontals they should be placed approximately one inch from TOP and BOTTOM.



Slide Connection Bar into lower leg assembly. Slide upper vertical over bar and secure both.

**WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING**

Part Number	Description
1	Right Leg Assembly
2	Left Leg Assembly
5	Upper Curved Vertical
6	Upper Curved Vertical
7	69" w Horizontal w/ Hinge Facing UP
8	69" w Horizontal w/ Hinge Facing DOWN
9	23" w Horizontal

Step 4

NOTE: When assembling horizontals they should be placed approximately one inch from TOP and BOTTOM.




Step 4:


NOTE: Can be assembled either face down on floor then lifted upright or upright as shown in drawings.

- A) Connect vertical extrusion [5 & 6] to leg assembly [2 & 1] using vertical connection bar as shown.
- B) Connect horizontal extrusion [8, 7, & 9] between vertical assemblies as shown by tightening BLACK knobs on backside of extrusion making sure Velcro faces toward BACK.

**NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.**



WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING




- Steps:
- 1) Place three large shelves atop pins. Refer to detail.
  - 2) Attach shelf supports [10-15] to assemblies [3].
  - 3) Velcro attach shelves atop shelf supports.
  - 4) Attach lights atop assembled backwall as shown.

**\*\* Various Accessories Available \*\***

WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING


Top View of Each Level



- Additional Items:**
- Setup Hardware
  - Graphic
  - (3) Lights


WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Top View of Each Level




WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

Top View of Each Level



Level 1



Level 2

- Additional Items:*
- Setup Hardware
  - Graphic
  - (3) Lights
  - Monitor Mount

WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING