


Top View



Perspective View

General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a **MILD NON-ABRASIVE** cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. **Heat and UV exposure will warp and fade components.**
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly


- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly




Part Identification - Numbering




Spline Connection



Base Plate & Extrusion Connection



Extrusion & Lock Connection




Engaged Lock



WARNING



DO NOT USE POWER TOOLS



LADDERS OR LIFTS MAY BE REQUIRED





ALL CONNECTIONS MUST BE TIGHTLY SECURED

Part Number	Description
A	Left Leg Assembly
B	Right Leg Assembly
C	Horizontal Extrusion
D	Horizontal Extrusion w/ Door Stopper

Step 1:

- 1) Connect lower horizontal extrusion [C] between bottom of leg assemblies [A] and [B], making sure bottom of [C] is aligned with bottoms of leg assemblies [A] and [B]. Tighten knobs to secure.
- 2) Insert **Infill** into grooves of Leg Assemblies [A] and [B].
- 3) Attach door between leg assemblies [A] and [B] and on top of **Infill**.
- 4) Attach upper horizontal extrusion [D] between leg assemblies [A] and [B], making sure top of [D] is aligned with tops of leg assemblies [A] and [B]. Tighten knobs to secure.



NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engaged, gently rock lock and extrusion back and forth while turning knob until lock fully opens.



Part Number	Description
E	Horizontal Extrusion
F	Horizontal Extrusion

Step 2:

- 1) Attach lower horizontal extrusion [E] between leg assemblies [A] and [B], making sure bottom of [E] is aligned with bottoms of leg assemblies [A] and [B]. Tighten knobs to secure.
- 2) Insert **Infill** into grooves of leg assemblies [A] and [B].
- 3) Attach upper horizontal extrusion [F] between leg assemblies [A] and [B] and on top of **Infill**, making sure top of [F] is aligned with tops of leg assemblies [A] and [B]. Tighten knobs to secure.
- 4) Place shelf, on top of pins, inside assembled workstation.
- 5) Set workstation top on top of assembled workstation, then secure with Velcro straps attached to underside of top.




Part Number	Description
G	Curved Extrusion



Step 3:

- 1) Slide connection bar into lower leg assembly. Slide upper vertical [G] over connection bar, then tighten set screws to secure together.
- 2) Attach monitor mount to vertical [G]. See [Monitor Mount Attachment](#) detail.

* Monitor Mount Attachment



Slide Monitor Mount into groove of Vertical Extrusion. Tighten Setscrews Attach Top Plate, then tighten screws.



Completed Assembly